

Rolling Background Support User Manual

Fixing Guide

Step 1: Install either one of the metal hook assemblies into a brick or breezeblock wall using the supplied expanding bolts (We recommend using coach screws for solid timber)

Step 2: Temporarily attach the background to establish the required length

Step 3: Install the other metal hook at the required position

Set Up Guide

Step 1: Insert the core at each end of your background onto the expanding plastic spiggots, ensuring they have not yet been expanded

Step 2: Place the background with the spiggots onto the metal hooks at each end

Step 3: Fix the chains onto the gears with a weight hanging beneath

Step 4: Twist the tightening wheel on each spigot until they stop expanding and have gripped the core firmly

Step 5: Adjust the chain if necessary to the desired length, removing unwanted chains. Joining them together when finished

Tips & Recommendations

Use suitable fixings if fixing to plaster or plaster board

When fixing to solid timber, we recommend the use of coach screws

When using a cotton muslin background, please use with a sturdy core where possible, we recommend using a metal core

Please note, the spiggots are reversible so the chain end can be on either the left or right side, whichever is most convenient.

Example kit:

Contents may vary dependent on kit size

